



Quick Connect Capture Plate

Trailair Triglide and Trailair Airbag/Shock Pin Box Long (L02- L09) Medium (M14 M23)

(Part# 331757 & #331758)

1. Slide the Capture Plate onto the king pin of your trailer, capturing the front of your pin box. The illustrations show the standard Triglide pin box which uses the 331757; the 331758 installs on the airbag/shock pin box.
2. Hold the Capture Plate tight against the bottom of the pin box's skid plate, tighten the 1/2" set screw to the trailer's king pin and tighten the set screw nut up to the wedge to lock in place (right).
3. Install the bolts onto the Capture Plate from the outside over the lip of the king pin's skid plate. These bolts are meant to help keep the plate in place while hooking up.
4. Thread the lockwasher and hex nut onto each bolt.
5. Tighten the hex nuts flush against the inside wall of the Capture Plate. (illustration to the right shows the front panel of the capture plate {331757 shown} transparent to better show how the bolts are installed)

