



Quick Connect Capture Plate LCI Rhino Pin Box

Part # 331723

Instructions

1. Place the **Capture Plate** hole over the kingpin and lift it flush against the king pin box plate.
2. Hold **Capture Plate** in place and tighten (2) **Set Screws** through the (1) **Front Bolt Plate**, also tighten (2) **Set Screws** (one on each side) through the (2) **Side Bolt Plates**.
3. The **Set Screws** should be tightened against the (4) **Shim Plates** to clamp the **Capture Plate** onto the king pin box as shown below.

