

Our Mounting Kits are better than the "other guy's" and are constructed from high quality materials made here in the USA. Our Universal kits fit more trucks without ordering extra kits, UMK and Custom Brackets are installed center of axle, and our Custom Brackets require less drilling and installs faster than most.

NOTE: In order to determine the total tow capacity of a system, you must consider the weight ratings of each component in that system. This includes, but may not be limited to, the rating of the tow vehicle, the fifth wheel hitch, and the hitch's mounting system. Actual tow capacity of the system will be equal to the lowest rated component.



SuperLite

SuperLite utilizes Clean Bed Technology with PullRite's exclusive SuperRail mounting systems, but can be used with any ISR Mounting System. **#2400 - 20K**



Super 5th

All ISR Super 5th models height adjustable from 16"-19".

#1900 - 16K
#2100 - 20K
#2200 - 24K



SuperGlide

All ISR SuperGlide models travel 14" to 18" depending on model.

#2700 - 16K
#2900 - 18K
#2300 - 24K

Universal	Universal HEAVY DUTY	Custom	Custom HEAVY DUTY	SuperRail
Fits Long or Short bed trucks.	Fits Long or Short bed trucks.	Fits Long or Short bed trucks.	Fits Long or Short bed trucks.	Fits Long or Short bed trucks.
Fits any ISR Series hitch (see note above).	HEAVY DUTY ISR Mounting Kits rated to 24K.	Fits any ISR Series hitch (see note above).	HEAVY DUTY ISR Mounting Kits rated to 24K.	Fits any ISR Series hitch (see note above).
Kit includes "L" Brackets, ISR Base Rails & Hardware	Ideal with models: #2200 ISR Super 5 th and #2300 ISR SuperGlide hitches, but fits any ISR Series hitch (see note above).	Kit includes Custom Mounting Brackets, ISR Base Rails, & Hardware	Ideal with models: #2200 ISR Super 5 th and #2300 ISR SuperGlide hitches, but fits any ISR Series hitch (see note above).	Includes totally removable SuperRails & Posts, Mounting Brackets & Hardware Features Clean Bed Technology!
\$181.58	\$361.75	\$344.47	\$526.92	from \$679.01
PullRite#	PullRite#	PullRite#	PullRite#	PullRite#

CHEVY / GMC

2016-2017	2500 & 3500 (NO DRILL) <i>(designed for easier install)</i>			2762		
2011-2017	2500 & 3500 (NO DRILL)			2724	2226	2328
2001-2016	2500 & 3500 HD	2720	2220			
1999-2010	2500 & 3500 HD			2734	2224	2326
2007-2017	1500 (6-1/2' bed)	2720		2730		

DODGE

2013-2016	3500 (NO DRILL)			2742		
2014-2017	2500 (NO DRILL)			2746		2336
2013	2500 (NO DRILL)			2740		
2003-2012	2500 & 3500 (*NO DRILL) <i>does not fit 3500 w/ overload springs</i>	2720	2220	2736*	2230*	2330*
2016-2017	1500 (does not fit w/ air bags)			2764		
2009-2015	1500 (does not fit w/ air bags)			2728		

FORD

2017	F250 & F350 (NO DRILL)					2332
2011-2016	F250 & F350 (NO DRILL)			2738	2228	2324
1999-2016	F250 & F350	2720	2220			2324
1999-2010	F250 & F350			2726	2228	
2015-2017	F150 (NO DRILL)			2760		
2004-2014	F150 (NO DRILL)			2732		

TOYOTA

2007-2016	Tundra (fits all bed lengths)			2748		
-----------	-------------------------------	--	--	------	--	--

NISSAN

2004-2012	Titan			2744		
-----------	-------	--	--	------	--	--



#4100 - 16K (shown)
#4400 - 20K

Trucks with less than 6' beds are usually not recommended for fifth wheel towing, however, with some trailer limitations, the #3100 SuperGlide may make towing possible. In cases where there will be less than 3" clearance between the cab and trailer, including a 90 degree turn, the #3100 is not recommended. Choose only from #3100 SuperRail Mounting Kit options. 22-3/4" of automatic slide.

Call for application info when king pin is located behind front edge of trailer.



#3100 - 12K

Universal	B&W Adapter Kits	SuperRail	#3100 SuperRail
Fits 6-1/2' bed trucks.	Fits 6-1/2' bed trucks.	Fits 6-1/2' bed trucks.	Fits 5-1/2' bed trucks. Use ONLY with #3100 SuperGlide.
Use with models: #4100 & #4400 SuperGlide hitches.	Use with models: #4100 & #4400 SuperGlide hitches.	Use with models: #4100 & #4400 SuperGlide hitches.	Includes removable SuperRails & Posts, Mounting Brackets and Hardware. The #3100 features a totally removable baserail design.
Kit includes "bolt to the bed" baserails, Universal "L" Brackets and Hardware	Kit includes B&W Adapter, removable Rails, Posts, Mounting Brackets & Hardware	Kit includes totally removable SuperRails & Posts, Mounting Brackets & Hardware.	Features Clean Bed Technology!
\$234.06	\$656.88	from \$634.88	from \$654.08
PullRite#	PullRite#	PullRite#	PullRite#

CHEVY / GMC

2011-2016	2500 & 3500 (NO DRILL)		4432	4428	
1999-2010	2500 & 3500	3340	4434	3345	
2007-2016	1500 (6-1/2' bed, new body style)			4423	
1999-2007	1500 (6-1/2' bed, except 2007 new body style)	3340		3345	
2007-2016	1500 (5'8" bed, current body style only)				3117
2004-2007	1500 (5'8" Bed, except 2007 current body style. Added limitations on trailers 98" or wider)				3114

DODGE

2013	2500 (NO DRILL)			4440	
2003-2012	2500 & 3500 (NO DRILL)		4433	3349	
2009-2017	1500 (5'7" & 6-1/2' bed, added limitations 96" or wider trailers)				3122
2002-2008	1500 (NO DRILL)			3349	
1995-2002	(except '02 1500)	3340		3346	

FORD

1999-2016	F250 & F350	3340	4431	4426	
2015-2017	F-150				3123
2004-2014	F-150 (6-1/2' bed)			3361	
1997-2003	F-150 (not SuperCrew)	3340		3342	
2009-2014	F-150 (5'7" bed, added limitations on 96" or wider trailers)				3119
2004-2008	SuperCrew F-150 (5'6" bed. Added limitations on trailers over 90" wide)				3113
2001-2003	SuperCrew F-150 (5'6" bed)				3111

TOYOTA

2007-2016	Tundra (Double Cab Only, 6-1/2' bed, Universal Rails with Custom Mounting Brackets)	4421			
2001-2006	Tundra (Standard Extra Cab)				3112
2007-2016	Tundra (Crew Max and 5'8" bed only)				3118

NISSAN

2004-2013	Titan Short Beds (Crew Cab limitations on trailers over 90" wide, King Cab may be used up to 102" wide—call for more information)				3115
-----------	---	--	--	--	------