



# Quick Connect Capture Plate Reese Revolution

(Part# 331721 and 331722)

**NOTE:** Plate #331721 is designed for use with Reese Revolution 10K king pin box. Plate #331722 is for use with both either 16K or 21K king pin boxes. If a wedge is present on your Reese Revolution king pin box, please remove prior to installation.

1. Confirm the "A, B and C" measurements of your trailer's king pin plate listed in the Quick Connect Capture Plate Chart before proceeding (visit our website at [www.pullrite.com](http://www.pullrite.com) for Fit Chart details).

**NOTE:** #331722 Capture Plate is pictured below, but BOTH plates are installed in the same manner; however, please note that the #331722 when used with the 16K Reese Revolution king pin box uses the 1/4" spacers (see below).

2. Holding the Capture Plate in place on the trailer's king pin box, tighten the Set Screw against the king pin.
3. To prevent the Set Screw from backing out, tighten the jam nut against the tab on the Wedge. Do not tighten the jam nut against or toward the king pin.

